SFIVIONP FINE WIRE STAPLER Sencomatic

STAPLER





Parts Reference Guide




Repair Kits YK0321 YK0398



Senco Products, Inc. 8485 Broadwell Road Cincinnati, Ohio 45244 Visit our Website www.senco.com Questions? Comments? call SENCO's toll-free Action-line: 1-800-543-4596 (North & South America only) or e-mail: toolprof@senco.com

SFW10XP Sencomatic Fine Wire Stapler






**Use Loctite #243 & Coat threads. HC0273 GC0833





NFG11D Revised April 21, 2003 (Replaces 4/10/03) © 2001, 2003 by SENCO Products, Inc. Cincinnati, Ohio 45244–U.S.A.



HG0085 (EU)

	Availal	ble F	Plugs
(Not	Included	with	Tool)





✓ Recommended Plugs
Plugs shown smaller than actual size

S/M Model	Α	D	E	F	G	Н	1	J
1D0005N	A06-D10	N/A	N/A	FC0425	GB0526	GB0532	GC0770	GC0769
1D2005N	A06-D10	N/A	N/A	FC0425	GB0536	GB0532	GC0770	GC0769
1D0015N	E06-E10	N/A	N/A	FC0426	GB0526	GB0533	GC0770	GC0769
1D2015N	E06-E10	N/A	N/A	FC0426	GB0536	GB0533	GC0770	GC0769
1D0025N	C06-C10	KB5145	GC0759	FC0418	GB0473	GB0527	GC0758	GC0763
1D2025N	C06-C10	KB5145	GC0759	FC0418	GB0475	GB0527	GC0758	GC0763
1D0035N	G06-G10	KB5145	GC0759	FC0419	GB0473	GB0528	GC0758	GC0763
1D2035N	G06-G10	KB5145	GC0759	FC0419	GB0475	GB0528	GC0758	GC0763
1D0045N	B06-B08	KB5144	GC0756	FC0420	GB0474	GB0529	GC0755	GC0763
1D2045N	B06-B08	KB5144	GC0756	FC0420	GB0476	GB0529	GC0755	GC0763
1D0055N	F06-F08	KB5144	GC0756	FC0421	GB0474	GB0530	GC0755	GC0763
1D2055N	F06-F08	KB5144	GC0756	FC0421	GB0476	GB0530	GC0755	GC0763
1D0065N	AT06-AT10	KB5144	GC0756	FC0422	GB0474	GB0531	GC0755	GC0763
1D2061N	AT06-AT10	KB5144	GC0756	FC0422	GB0476	GB0531	GC0755	GC0763

E

SFW10XP Sencomatic Fine Wire Stapler
REPLACEMENT PARTS LIST•LISTA DE PARTES DE REPUESTO•ERSATSTEILE-LISTE•LISTE DE PIÈCES DE RECHANGE

PART NO.	<u>DESCRIPTION</u>	<u>DESCRIPCIÓN</u>	<u>BESCHREIBUNG</u>	<u>DÉSIGNATION</u>
AB0124			.GEHÄUSE	
AC0217 BB0200			.PLATTEPUFFER	
BC0349	. CAP	TAPA	.KAPPE	BOUCHON
BC0351	. CYLINDER	CILINDRO	.VENTIL-ZUSAMMENBAU	CYLINDRE
			.DICHTUNGDICHTUNG	
BF0221	. SEAL (F & G)	SELLO	.DICHTUNG	JOINT
			.DICHTUNG	
CC0208	. PISTON, LOWER	PISTON	.KOLBEN	PISTON
			.KOLBEN	
CC0211			.KAPPE	
CF0041	. HOUSING	ALOJAMIENTO	.GEHÄUSE	CORPS
			VENTILSTIFTGEHÄUSE	
CF0044	. SEAL	SELLO	.DICHTUNG	JOINT
EA0036	. PISTON ASSY (C) . PISTON ASSY (F)	ASAMBLE DE PISTON	.KOLBEN-ZUSAMMENBAU	PISTON D'ASSEMBLEE PISTON D'ASSEMBLÉE
EA0038	. PISTON ASSY (Ġ)	ASAMBLE DE PISTON	.KOLBEN-ZUSAMMENBAU	PISTON D'ASSEMBLÉE
			.KOLBEN-ZUSAMMENBAU	
EA0130	. PISTON ASSY (AT)	ASAMBLE DE PISTON	.KOLBEN-ZUSAMMENBAU	PISTON D'ASSEMBLÉE
FC0418	. GUIDE BODY (C)	PLACA DE NARIZ	.KLAMMERFÜHRUNG	FRONT
			.KLAMMERFÜHRUNG	
FC0421	. GUIDE BODY (F)	PLACA DE NARIZ	.KLAMMERFÜHRUNG	FRONT
			.KLAMMERFÜHRUNG	
FC0426	. GUIDE BODY (E)	PLACA DE NARIZ	.KLAMMERFÜHRUNG	FRONT
GB0473	. RAIL ASSY (C) (US)	ASAMBLE DE CARRIL	.FEDERSCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
GB0474	RAIL ASSY(B & AT) (US)	ASAMBLE DE CARRIL	.SCHIENE-ZUSAMMENBAUSCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
GB0476	. RAIL ASSY(B & AT)(Euro)	ASAMBLE DE CARRIL	.SCHIENE-ZUSAMMENBAU	RAIL D'ASSEMBLÉE
			.VERSCHLUSS	
GB0527	. HOUSING (C)	ALOJAMIENTO	.GEHÄUSE	CORPS
GB0528 GB0529	. HOUSING (G) . HOUSING (B)	ALOJAMIENTOALOJAMIENTO	.GEHÄUSEGEHÄUSE	CORPS
GB0530	. HOUSING (F)	ALOJAMIENTO	.GEHÄUSE	CORPS
GB0532	. HOUSING (A)	ALOJAMIENTO	.GEHÄUSE	CORPS
			.GEHÄUSESCHIENE-ZUSAMMENBAU	
GC0735	. PLATE	PLACA	.PLATTE	PLAOUE
GC0755 GC0756	. FEEDER SHOE (C) . ROLLER (B.F & AT)	ALIMENTADORRODILLO	.KLAMMERSCHIEBER	POUSSOIR GALET
GC0757	. HOUSING (B & AT)	ALOJAMIENTO	.GEHÄUSE	CORPS
GC0759	ROLLER (C &G)	RODILLO	ROLLE	GALET.
			SICHERUNGSRING	
GC0770	. FEEDER SHOE (A & E)	ALIMENTADOR	.KLAMMERSCHIEBER	POUSSOIR
			SICHERUNGSRINGSTIFT	
			STIFTHEBEL	
HF0088	. TRIGGER	GATILLO	.AUSLÖSER	GACHETTE
HG0075 HG0083	. SAFETY LABEL (US)	ETIQUETA	.AUFKLEBER	ETIQUETTE ÉTIQUETTE
KB0010	. SCREW	TORNILLO	.SCHRAUBE	VIS
			SCHRAUBESCHRAUBE	
			SCHRAUBEFEDER	
KB4300	. SPRING	RESORTE	.FEDER	RESSORT
			STIFTSTIFT	
KB5249	. SCRÈW	TORNILLO	.SCHRAUBE	VIS
			.DICHTUNGDICHTUNG	
LB0015	. SEAL	SELLO	.DICHTUNG	JOINT
LB0021	. SEAL	SELLO	.DICHTUNG	JOINT
			.DICHTUNGDICHTUNG	
LB0069	. SEAL	SELLO	.DICHTUNG	JOINT
			.DICHTUNGDICHTUNG	
LB0894	. SEAL	SELLO	.DICHTUNG	JOINT
LB0903	. SEAL	SELLO	.DICHTUNGDICHTUNG	JOINT
			.DICHTUNGDICHTUNG	
			DICHTUNG	